

د رادون تست (Radon Test) لارښوونې

1. د ورق کڅوړه پرانیږئ او تور قوطی لرې کړئ. قوطی مه پرانیږئ.
2. د تست ابي رنگ فورمه کې د بارکوډ شمېره ولیکئ. د بارکوډ شمېره د قوطي په څنگ کې چاپ شوې.
3. د تست په ابي رنگ فورمه کې او د پرمختګ کارت کې د رادون تست (Radon Test) شا ته د پیل نېټه ولیکئ. **که د پیل نېټه نه وي لیکل شوې، نو د تست پایله به ترلاسه نه کړئ.**
4. قوطي د رادون تست (Radon Test) پرمختګ کارت په سر باندې د اوسېدو په یوه ځای لکه د خوب خونه، د اوسیدو خونه، د ډوډۍ خونه، دفتر یا د لوبو خونه کې ځای پر ځای کړئ. قوطی باید لږترلږه له فرش څخه 20 انچ لوړ او له بیروني دروازو او کړکیو څخه لږترلږه درې فوټه لیرې ځای په ځای شي. د تست په بهیر کې نور شیان له قوطي څخه لږترلږه 4 انچه لیرې وساتئ.
5. د تست ابي رنگ پاتې فورمه ډکه کړئ او له قوطي سره یې وساتئ.
6. د تست د دورې په پای کې، د تست په ابي رنگ فورمه او د پرمختګ کارت کې د رادون تست (Radon Test) شاته د پای نېټه ولیکئ. **که د پای نېټه لیکل شوې نه وي، نو د تست پایله به ترلاسه نه کړئ.**
7. قوطی، د تست بشپړه شوې ابي رنگ فورمه او بشپړ شوی رادون تست (Radon Test) د پرمختګ په کارت کې د تحلیل لپاره RSSI ته بیرته ور واستوئ.

ډاډمنه کړئ چې:

- د تست کېټ په ترلاسه کولو سره ژر تر ژره تست پیل کړئ.
- قوطی په خپل کور کې د اوسېدو تر ټولو ټیټه ساحه کې لکه د لومړي پور د اوسېدو خونه یا د کورنۍ د زیرزمینۍ یعنی بیسمینټ خونه کې ځای پر ځای کړئ.
- لږترلږه د 3 میاشتو لپاره تست ترسره کړئ، خو په خواپورې توګه له 6 څخه تر 12 میاشتو پورې.
- د تست په دوره کې د ژمي موسم شامل کړئ.
- خپل د ګرمولو او سړولو سیستمونه، د کړکۍ او دروازو پرانیستلو یا بندولو په شمول، داسې وکاروئ څنګه چې یې معمولاً کاروئ.
- قوطی وچ وساتئ.

لاندي موارد مه ترسره کوئ:

- تور قوطی مه پرانیږئ یا له قوطي څخه سپین لیل مه لیرې کوئ.
- قوطی په تشناب، پخلنځی، د مینځلو خونه، سالون، الماری یا مسترینوب خونه کې مه اېږدئ. قوطی په زیرزمینۍ یعنی بیسمینټ کې مه اېږدئ، مګر دا چې د اوسېدو ځای ولري.
- د تست په بهیر کې قوطي ته حرکت مه ورکوئ یا یې مه ګډوډوئ.
- هڅه مه کوئ چې په پایلو کې لاسوهنه وکړئ.

په HealthVermont.gov/radon کې د رادون تست (Radon Test) د بشپړولو د څرنگوالي په ګام پر ګام ویدیو (په انګلیسي ژبه) وګورئ..

بشپړه شوې فورمه او قوطي بیرته ورته واستوئ:

RSSI

6312 Oakton Street

Morton Grove, IL 60053

پوښتنې شته؟ د رادون له پروګرام (Radon Program) سره اړیکه ونیسئ:

تلیفون: 1-800-439-8550

برېښنالیک: radon@vermont.gov

وېبسایت: HealthVermont.gov/radon (په انګلیسي ژبه)

Radon Test Instructions

1. Open the foil pouch and remove the black canister. Do not open the canister.
2. Write the barcode number on the blue testing form. The barcode number is printed on the side of the canister.
3. Write the start date on the blue testing form and on the back of the Radon Test in Progress card. **You will not get a test result if there is no start date written down.**
4. Place the canister on top of the Radon Test in Progress card in a living space, like a bedroom, living room, dining room, office, or playroom. The canister should be placed at least 20 inches from the floor and at least three feet from exterior doors and windows. Keep other objects at least 4 inches away from the canister during the test.
5. Fill out the rest of the blue testing form and keep it with the canister.
6. At the end of the testing period, write the end date on the blue testing form and on the back of the Radon Test in Progress card. **You will not get a test result if there is no end date written down.**
7. Return the canister, completed blue testing form and completed Radon Test in Progress card to RSSI for analysis.

Make sure to:

- Start the test as soon as you get the test kit.
- Place the canister in the lowest living area of your home, like a first floor living room or basement family room.
- Test for at least 3 months, but ideally for 6 to 12 months.
- Include a winter season in the testing period.
- Use your heating and cooling systems, including opening or closing windows and doors, as you normally would.
- Keep the canister dry.

Do not:

- Do not open the black canister or remove the white label from the canister.
- Do not put the canister in a bathroom, kitchen, laundry room, hallway, closet, or mechanical room. Do not put the canister in a basement *unless* it contains living space.
- Do not move or disturb the canister during the test.
- Do not try to manipulate the results.

Watch a [step-by-step video of how to complete your radon test at HealthVermont.gov/radon](https://www.healthvermont.gov/radon) (in English).

Return completed form and canister to:

RSSI
6312 Oakton Street
Morton Grove, IL 60053

Questions? Contact the Radon Program:
phone: 1-800-439-8550
e-mail: radon@vermont.gov
website: HealthVermont.gov/radon (in English)